

How to Program LiftMaster Remote

Garage door openers are a convenience that sometimes go under-appreciated. When the remote entry does not seem to communicate properly, owners can become frustrated. If you find that your remote does not communicate well with your opener, consider reprogramming your remote by re-synching them. You will need to program any new remotes that you may buy as well. Fortunately, programming your LiftMaster remote is easy and will only take a short time.

Instructions

Things You'll Need

Step ladder

- 1.) Set up a step ladder in your garage beneath the garage door opener motor unit. Place the remote(s) that you wish to program in your pocket and ascend the ladder until you can reach the unit.
- 2.) Locate the "Learn" button on the garage door opener's main motor unit. Press the "Learn" button and the LED will light up.
- 3.) Press and hold the button on the remote that you wish to program. This must be done within 30 seconds of pressing the "Learn" button.
- 4.) Release the button on the remote when you see the LED on the main motor unit blink. If the LEDs are not active, you will hear two clicks when the remote has learned the code.
- 5.) Press the button on the remote to test it once you have descended the ladder.